

IMAGINATION GALLERY

Using Super Color® EZ Transfers

For use with **LIGHT COLORED SHIRTS**, Mouse Pads, puzzles, cloth bags, aprons, hats and more

PRINTING WITH YOUR COLOR INK JET PRINTER

- Print "mirror image" on **BLANK SIDE** of this unique Premium Transfer Material using your color ink jet printer.
- Do Not print more than one transfer at a time.
- Print photographs, artistic designs and patterns ... Use your imagination.
- Before you print your design on the transfer material, either "flip" your design horizontally OR set the "media options" setting on the printer driver to "Reverse Printing," T-Shirt Transfer Sheet," "Mirror Image," or "Back Print Film" setting
- Remember - The image must be printed on the transfer media in mirror image so that it will appear correctly when transferred.

IRONING INSTRUCTIONS

- For best results, cut away the unprinted transfer material. Cut close to the printed design.
- Pre-Heat iron to the highest NonSteam Setting according to your iron, for 8 to 10 minutes. **DO NOT** use steam.
- Place material on which the image is to be transferred on a clean smooth surface.
- Be sure material is wrinkle free. Center transfer on garment, printed side down.
- Starting at one edge of the transfer material, push the iron slowly along the long side of the transfer - using body pressure while pressing down on iron for at least 15 to 20 seconds. Be sure to heat entire surface. **KEEP MOVING THE IRON** evenly across the transfer.
- Repeat this process making sure entire transfer is heated.
- Pay special attention to all edges and corners.
- **FOR A GLOSSY FINISH** ... Allow transfer to cool and then peel backing from fabric. **Transfers work best when allowed to cool before removing backer.**
- **FOR A SATIN FINISH** ... After heating entire transfer surface, peel transfer backing from fabric within 2 to 5 seconds. Gently smooth the fabric with your hands and allow to cool for 3 to 5 minutes.

It is **NOT NECESSARY** to **PRE-WASH** Shirts on to which Super Color Transfer Images will be applied

- **Washing Instructions** : Follow normal washing instructions.
ONLY USE COLD WATER and a detergent with color protection
- When washing t-shirt, turn shirt inside out before washing. Remove immediately after wash is completed.
- Tumble Dry in dryer under normal setting or air dry.
Areas on which the transfer has been applied may feel stiff when new. These areas will become soft as garment is washed.
If you need to iron garment, **DO NOT IRON DIRECTLY ON TRANSFER**
Cover the transfer with Teflon, silicone or baking parchment before ironing.

Please follow ironing, washing and other instructions carefully

Failure to follow these instructions may lead to unsatisfactory results.

The Imagination Gallery and/or product distributors assume no responsibility for damage to ironing surface, garments or fabrics.