

MICRO FORMAT

# IMAGINATION GALLERY

SM

## FABRIC CARRIER™

A revolutionary new product -- designed for the craft enthusiast.  
Now you can easily and quickly turn your computer printer into a "crafting machine."

Use the IMAGINATION GALLERY FABRIC CARRIER with your favorite cotton or cotton blend fabric to print dazzling displays of design and color on your color ink jet printer

### DIRECTIONS FOR USE

1. READ ALL DIRECTIONS IN FULL *BEFORE* STARTING YOUR PROJECT.
2. Place your FABRIC CARRIER on a flat surface, *blank white side down*.
3. The face covering on this carrier is designed to be peeled away one segment at a time. Please observe where the diagonal slits in the covering occur before peeling.
4. Peel away the top left hand covering segment. Adhere fabric --- wrong side down --- to the outermost edge of the Fabric Carrier. Be sure to cover all sticky areas of the carrier with the fabric.

Note: You may want to experiment with different materials and weights to determine which weight works best with your printer.

5. Continue to peel the covering, one segment one at a time. As you peel back each section, adhere fabric to the Fabric Carrier. Adjust fabric as you go. Wrinkles or folds are easily cleared away --- just lift and reposition the fabric.
6. Before printing, check the carrier to be sure that fabric is covering all sticky areas. If sticky areas remain, trim away excess carrier before printing.  
**DO NOT FEED ANY STICKY AREAS OF THE CARRIER INTO YOUR PRINTER.**
7. To insure ease of removal from carrier, **PRINT IMMEDIATELY AFTER MOUNTING FABRIC ON CARRIER SHEET.** Feed into printer *one sheet* at a time. Print directly on the fabric. Note: Colors will appear differently on various fabrics.
8. After printing, carefully remove the Fabric Carrier from the fabric. The special formulated adhesive is designed to release from the fabric, leaving no sticky residue...
9. We recommend discarding after two uses.

Manufactured in the USA



SLIT